





First, gather all the required materials and equipment. This includes the cartridge gun and if necessary, the aluminium locking ring, shrink-wrapped cartridge and associated mixer and a nozzle that suits your need.







Start applying the adhesive.



open the cap by turning it, and remove the plug. **ATTENTION!** The circlip for F-system





Insert the cartridge, push the drive rod forwards and close the interlocking device lever.



To maintain a continuous flow without stopping the gun, set the dosage regulator to zero (= 0).



Now evenly press out approx. 3 to 4 cm of the material.



Here you can find our application video.

www.dinitrol.com/2cgun



THE QUALITY SOLUTION

dinitrol.com

DINOL GmbH

Pyrmonter Straße 76 D-32676 Lügde Phone +49 (0) 5281-98298-0 Fax +49 (0) 5281-98298-60 info@dinol.com www.dinol.com

